## - - - - CLEANING PAPER - - - - -

## For details, refer to the Maintenance Chapter in your printer manual

Procedure : (Do every time EP-L cartridge is replaced)

- 1. If optional paper cassette is installed, tray selection must be 'MP TRAY'.
- 2. Place this page, this side up, on the top of the paper stack in the MP tray.
- 3. Run another test page. (Cleaning once is sufficient)

